



NOTES:

1. All connecting plumbing to be 1/4" tube size.
2. Control cylinder end caps must be ported with -4 S.A.E.
O-Ring port for external plumbing. Consult pump Mfg.
3. Plumbing layout is for control of pump port "A" & "B".

**HYDRAULICS, INC. NOT RESPONSIBLE
FOR PUMP WARRANTY**

**RAPID RESPONSE TORQUE CONTROL FOR SUNSTRAND
HYDRO-TRANSMISSION - SERIES 20 THRU 27**